



**ELECTRICAL CONNECTIONS**  
 TYPICAL GENERATOR/ POWERCORD

**WARNING**  
 MULTIPLE 120/240 VOLT POWER SOURCES. ALL MUST BE SECURED OFF BEFORE SERVICING. REFER SERVICE TO A QUALIFIED ELECTRICIAN.

**NOTE**  
 120/240 VOLT TRANSFER SWITCHES MAY NOT OPERATE IF POWER IS LOST ON ONE HOT LEG WHEN RUNNING ON 240 VOLTS.

Use copper wire only  
 75° C. minimum.